

Manual guide



ProWatchly

System configuration

Power Connection:

- Connect the power adapter to the setup box and ensure it is securely plugged into a power source.

Display Connection:

- Attach the monitor or screen to the setup box using an appropriate cable (HDMI, VGA, or DisplayPort, as applicable).

Network Setup:

- **For IP Cameras:**
 - a. Connect the Power over Ethernet (PoE) switch to the setup box using a LAN cable.
 - b. Ensure the LAN cable is securely connected to both devices.
- **For DVR-Based Systems:**
 - a. Connect the LAN cable from the DVR to the setup box.

Note: Most of these configurations are typically completed during the setup process with assistance from our representative.

Camera Installation:

- Connect the cameras to the PoE switch using compatible Ethernet cables. Ensure all connections are firm and the cameras receive power through the PoE switch.

Power On:

- Turn on the setup box and verify that all connected devices are powered on and functioning.

Login

Power On:

- After turning on the ProWatchly setup box, wait for the system to boot up.

System Login:

- Log in to the system using the default credentials:
 - **Username:** **Client**
 - **Password:** **helloclient**

Launch Application:

- Open the ProWatchly application from the system's desktop or start menu.

ProWatchly Login:

- Log in to the ProWatchly application using the credentials provided by ProWatchly representative.